




# Switch Settings

## Mars Electronics VN-4000 & VN4010XV



Switch 4 (Best Change)	Switch 5 (Emulation)	
OFF	OFF	Setting for VN4010XV only on a machine with a \$1 coin payout line. Cassette 5,10,25,\$1 coins. All VN 4000 and other VN4010XV configurations must use this settings
ON	ON	