

# American Changer

## Series 1000 Switch Settings

Error Codes are for PCB's with **RED** LED

The errors will show on the LED while holding the DUMP button:

- 1---- : Hopper was shut down completely.
- 2--- : Hopper Exit eindow LED is blocked.
- 3-- : Low coin failure.
- 23-- : Hopper is jammed.
- 4- : Hopper overpaid 2 coin and was shutdown (jackpot).
- 5 : Hopper is not plugged into harness



Switch	1	2	3	4	5	6	7	8
<b>MEI 2501 Series</b>	OFF	ON	OFF	ON	OFF	ON	OFF	OFF
<b>MEI 2601 Series</b>	ON	ON	ON	ON	OFF	ON	OFF	OFF



888.396.8363 - Atlanta  
800.248.1712 - Orlando

[www.vendorsrepair.com](http://www.vendorsrepair.com)

V  
R  
S  
  
T  
E  
C  
H  
  
T  
I  
P  
S