

American Changer Series 2000 Switch Settings

The Errors will show up while holding the DUMP button. (Depending on board revision)

- 00000 = No Errors
- 00100 = Low Coin-Left Hopper
- 00001 = Low Coin Right Hopper
- 00200 = Exit Window Jam on Left Hopper
- 00002 = Exit Window Ja, on Right Hopper
- 00300 = Bad Logic Board on Left Hopper
- 00003 - Bad Logic Board on Right Hopper
- 00400 = Jammed on Keft Hopper
- 00004 = Jammed on Right Hopper
- 01000 = Jackpot on Left Hopper
- 00010 = Jackpot on Right Hopper

Note: Some errors may combine



Switch	1	2	3	4	5	6	7	8
MEI 2501 Series	OFF	ON	OFF	ON	OFF	ON	OFF	OFF
MEI 2601 Series	ON	ON	ON	ON	OFF	ON	OFF	OFF



888.396.8363 - Atlanta
800.248.1712 - Orlando

www.vendorsrepair.com

V
R
S

T
E
C
H

T
I
P
S